


All console nds/ndsl/ndsi/3ds under 3.0 can use for upgrading r4igold.


1 To download the " Update\_3DS3.0.0\_GOLDCC " into the TF card root directory, then open the NDSI console, press "A" button to enter the "GAME" directory.




2 Select "Update\_3DS3.0.0\_GOLDCC", press "A" to enter the upgrading procedure.



3 Press "START" to start upgrading.



#### 4 Upgrading Process....



5 Upgrading completed, power off the ndsi conosle .Now r4igold had upgraded to v3.0 version successfully, can work with the 3ds v3.0.0-5 console .

